

Operating Instructions

863 Valley View Road, Eighty Four, PA 15330 USA Tel: 724-941-9701 • www.skcinc.com

Exciting News!

On July 15, 2019, SKC Inc. acquired Colormetric Laboratories, Inc. (CLI).

SKC is excited to add CLI surface and dermal assessment and control tools to our highly respected, long-standing sampling solutions that help you maintain the health and safety of workers. SKC looks forward to continuing to provide the same great CLI products with excellent customer and technical support. Learn more about SKC Inc. at https://www.skcinc.com/about.

Surface SWYPE for PhenoIs Cat. No. 769-1027

- 1. Lightly spray the area or item (e.g., workbench, tool, control knob) with Developing Solution for Phenols Cat. No. 769-1067.
- 2. Wait at least 30 seconds and then wipe with a Surface SWYPE pad.
- 3. Allow 3 minutes for the color to develop on the pad. A red color is specific for phenol.

SKC Limited Warranty and Return Policy