

## **Operating Instructions**

863 Valley View Road, Eighty Four, PA 15330 USA Tel: 724-941-9701 • www.skcinc.com

## **Exciting News!**

On July 15, 2019, SKC Inc. acquired Colormetric Laboratories, Inc. (CLI).

SKC is excited to add CLI surface and dermal assessment and control tools to our highly respected, long-standing sampling solutions that help you maintain the health and safety of workers. SKC looks forward to continuing to provide the same great CLI products with excellent customer and technical support. Learn more about SKC Inc. at https://www.skcinc.com/about.

## Skin SWYPE for Aromatic Isocyanates Cat. No. 769-1032

- 1. Wipe the skin with the cloth portion of the Skin SWYPE pad.
- 2. Pour ¼ inch of Developing Solution for Isocyanates Cat. No. 769-1062 into the small cup provided.
- 3. Put the Skin SWYPE pad in the cup, cloth end down and color detection strip up. The developing solution will wick up to the color detection strip and a color change will occur if contamination is present.
- 4. Allow 3 minutes for color to develop on the strip. A red-orange color is specific for isocyanates.

## **SKC Limited Warranty and Return Policy**