IOM Sampler

A Gold Standard for Personal Inhalable Particulate Sampling

IOM Sampler

Only the authentic IOM Sampler developed by the Institute of Occupational Medicine (IOM) in Scotland has been tested by the Health and Safety Laboratory, Health and Safety Executive (HSE) in the UK and verified to meet the ISO/CEN convention (ISO 7708).* The IOM Personal Inhalable Sampler is a sampling head that houses a reusable 25-mm filter cassette with specified filter for the collection of inhalable airborne particles. When attached to a personal sampling pump operating at 2 L/min and clipped near a worker's breathing zone, the IOM effectively traps particles up to 100 µm in aerodynamic diameter and **closely simulates how airborne workplace particles are inhaled through the nose and mouth**. The plastic cassette with filter is weighed as a single unit before and after sampling for gravimetric analysis. A stainless steel IOM cassette can be used for chemical analyses and bioaerosol sampling.

IOM Accessories



- Cassette
 Conductive plastic or stainless steel
- Transport clip and cover Protect loaded filter cassette without IOM body during transportation



IOM MultiDust Sampling

Using the IOM Inhalable Sampler with a MultiDust foam disc and filter transforms the IOM into a versatile personal dust sampler, able to separate and collect inhalable and respirable fractions simultaneously. By inserting a MultiDust polyurethane foam (PUF) disc of specific porosity into the IOM cassette inlet, **respirable** particles can be collected on the filter at the back of the cassette. The sample collected on the foam can be weighed with the filter to determine the **inhalable** fraction. Analysis is gravimetric.

* Reference: Kenny, et al., "A Collaborative European Study of Personal Inhalable Aerosol Sampler Performance," Ann. Occup. Hyg., Vol. 4, No. 2, 1997, pp. 135-153

Meets U.S. and international standards

- ACGIH sampling criteria for inhalable particulate
- ISO[®]/CEN health-related fractions of bioaerosols
- Preferred sampler for HSE Method MDHS 14/4
- NIOSH Method 5700 for particulate formaldehyde
- Australian standard for inhalable particulate
- Complies with MDHS 25/3 for organic isocyanates (stainless steel model only)
- Complies with MDHS 6/3 for lead (with accessory head)
- OSHA-equivalent method for particulates not otherwise regulated (PNOR)[‡]

Economical and reusable

Small and lightweight

- Plastic model weighs less than 2 ounces (55 grams)
- Efficient particulate sampling up to 100 µm

Maintains sample integrity

- Removable 25-mm cassette system eliminates filter handling
- Cassette and filter are weighed as a single unit to include
 all collected particles in analysis

Stainless steel cassette available for chemical analysis

- Autoclavable for bioaerosol sampling
- Use with MultiDust Foam Discs for simultaneous inhalable and respirable dust
 - Determine respirable dust only by weighing the filter only
- ‡ Reference: OSHA letter November 8, 2011; contact SKC for a copy





Air Sampling Solutions & Expertise skcinc.com

A Gold Standard for Personal Inhalable Particulate Sampling

Performance Profile

Flow Rate:	2 L/min*
50% Cut-point:	100 μm at 2 L/min inhalable fraction 4.0 μm at 2 L/min respirable (with MultiDust)
Construction:	Molded conductive plastic (polypropylene) or stainless steel
Maximum Operating	
Temperature:	Plastic IOM and cassette: 212 F (100 C) with no pressure [†] Stainless steel IOM and cassette: 392 F (200 C) - suitable for autoclaving and solvent washing
Filters:	25-mm membrane or fibrous filter
Weight: (plastic model with cassette)	< 2 oz (55 gm)
Analysis:	Gravimetric or chemical (stainless steel model)
Tubing:	1/4-in ID

- * For sampling at higher flow rates, see Technical Note 1977 at www.skcinc.com/catalog/ pdf/instructions/1977.pdf
- *†* The plastic IOM is not suitable for autoclaving or ethylene oxide sterilization.

References

Mark, D. and Vincent, J. H., "A New Personal Sampler for Airborne Total Dust in Workplaces," Ann. Occup. Hyg. Vol. 30,1986, pp. 89-102

ACGIH Technical Committee on Air Sampling Procedures: Particle Size-selective Sampling in the Workplace, ACGIH, Cincinnati, Ohio, 1984

Kenny, L.C., Bowry, A., Crook, B., and Stancliffe, J.D., "Field Testing of a Personal Size-selective Bioaerosol Sampler," American Occupational Hygiene, Vol. 43, No. 6, 1999, pp. 393-404

Kenny, L.C., Chung, K.Y.K., Dilworth, M., Hammond, C., Jones, J. Wynn, Shreeve, Z., and Winton, J., "Applications of Low-cost Dual-fraction Dust Samplers," Ann. Occup. Hyg., Vol. 45, No. 1, 2001, pp. 35-42

Wang, C. et al., Field Evaluation of Personal Sampling Methods for Multiple Bioaerosols at doi: 10.1371/journal.pone.0120308.

SKC Limited Warranty and Return Policy

SKC products are subject to the SKC Limited Warranty and Return Policy, which provides SKC's sole liability and the buyer's exclusive remedy. To view the complete SKC Limited Warranty and Return Policy, go to http://www.skcinc.com/warranty.

Size-selective Bioaerosol Sampling

Previously used only for sampling chemical particles, the IOM Sampler with MultiDust foam disc has been tested by the HSE's Health and Safety Laboratory (UK), which has determined it to be an effective size-selective sampler for bioaerosols.

It has been shown that the IOM Sampler, loaded with a usersterilized polycarbonate filter** and MultiDust polyurethane foam disc,** is not only an efficient collector of inhalable and respirable fractions of bioaerosols, but it also better maintains survivability of microorganisms when compared to filter-only sampling. This has been attributed to the MultiDust foam's large surface area and open cell structure, which diffuses airflow to reduce microbial dehydration. Analysis is by growth culture or microscopy.

A study, using culture assay, epifluorescence microscopy, and microscopy analyses, has determined that the IOM Sampler loaded with a polycarbonate filter provides efficient sampling for personal exposure assessment of multiple bioaerosols, particularly bacteria.

** The MultiDust foam disc must be washed and sterilized with UV light and the polycarbonate filter autoclaved before sampling. For optimum results, handle all components of the sampler and media with sterile gloves and forceps before and after sampling.

Ordering Information

IOM Samplers, use with filter, select from below	Cat. No.
IOM Sampler and cassette, [‡] in conductive plastic, with transport clip	225-70A
and cover	
IOM Sampler and cassette, [‡] in stainless steel, with transport clip	225-76A
and cover	
IOM Sampler, [‡] in conductive plastic, with stainless steel cassette,	225-79A
transport clip, and cover	
Accessories	
Cassette assembly, in conductive plastic, with transport clip and cover	225-71A
Cassette assembly, in stainless steel, with transport clip and cover	225-75A
Transport Clip and Cover for cassette	225-72A
IOM Calibration Adapter	391-01
Single Hole Lead Head, for sampling lead to MDHS 6	225-52
Seven Hole Head	225-50
Asbestos Head, 25-mm cowled aluminum sampler designed for use	225-54A
with a gridded filter as per HSG (UK) 248 for asbestos fibers	

MultiDust Foam Discs, use with filters, select from below		
MutiDust Foam Discs for Respirable and Inhalable PM	pk/10	225-772
	pk/50	225-772-50

25-mm Filters, each sample requires its own filter	
PVC, 5.0 μm, pk/100	225-5-25
Glass Fiber, 1.0 µm, pk/500	225-702
MCE , 0.8 μm, pk/100	225-1930
Polycarbonate, 0.8 μm, pk/100	225-1601
Gelatin, sterilized, pk/50	225-9551

‡ A 25-mm filter is required for sampling with the IOM; see above.

